

SANDERS HELPER®

DECK AND FLOOR SANDERS HELPER



PATENTED: 9333615, 9623534

Sanders Helper is a way to sand decks and floors using random orbital sanders.

To use Sanders Helper, first turn Sanders Helper so that you can slide a random orbital sander in to one or both brackets from the side. You can adjust the brackets to use one or two random orbital sanders.

Tighten the sanders into the brackets using the Velcro straps. Turn the sanders on then turn the Sanders Helper over with the handle up, plug the cords from the sanders into the outlets on the handle with the switch in the off position. You can hang the extra cord from the sanders on the Velcro strap on the handle. Now plug the outlets into the extension cord.

When ready to use, simply switch on the outlets, the sanders will start and you will be ready to sand.

Using two sanders saves time, money and your knees because Sanders Helper will do most of the sanding while you are standing.

Don't forget the sand paper!

MULTIINCPRODUCTS.COM



SANDERS HELPER

38996 Highway 82
Suite 338
Aspen, CO 81611
970-319-9161
multiinc@outlook.com

